







Assembly Instruction


Item No.44681 Activity Walker - Crocodile

Attention: Tighten the screws until proper resistance. The screws used to secure the wheels should not be loosen as the wheels rotate.


A  x14 B  x4 C  x4 D  x4 E  x2




3



4



5



WARNING:

This toy is required to be assembled by adults only. Do not use close to the ear! Misuse may cause damage to hearing.